


PORFOLIO PROJECT OF RIYAN SEPTIANA

1. LabVIEW




This project integrates **LabVIEW** as a *Human Machine Interface (HMI)* to control a motor and lamp based on sensor inputs. A temperature sensor regulates motor speed, while an ultrasonic sensor controls the lamp. The system allows users to define input/output pins, monitor servo angle, and visualize logic indicators in real time.

Key Features:

- LabVIEW-based HMI integration
- Motor control using temperature sensor input
- Lamp control with ultrasonic sensor input

Technology: LabVIEW, Arduino, Temperature Sensor, Ultrasonic Sensor, Servo Motor






2. Pneumatic

This project simulates a pneumatic sequencer system controlling three actuators to perform unit transfer operations. The process begins with a **driver lifter** descending to pick up the unit, then the lifter laterally moves to another conveyor to place the unit at a specific location detected by sensors. Once the unit is positioned on the conveyor, the conveyor transports the unit to the next station.

Key Features:

- Pneumatic actuator sequencing (pick → transfer → place)
- Sensor-based interlocking to ensure safe, ordered steps
- Timing and sequence logic to prevent race conditions and collisions
- Integration of position sensors with solenoid valve control via PLC


Technology: Pneumatic actuators (single/double-acting), Proximity/Position Sensors, Solenoid Valves, PLC Interface, Ladder Logic / Sequential Function Chart



Sequential :

- Single cylinder down
- Vacuum on
- Single cylinder up
- Linear driver slides to another conveyor
- Single cylinder down
- Vacuum off
- Single cylinder up
- Linear driver slides to the first conveyor

Sequential diagram



B+ = START and Sequence1

C+ = B1 and Sequence1

E2 = C1 and Sequence1

B - = Sequence2

A+ = B0 and Sequence2

E3 = A1 and Sequence2

B+ = Sequence3

C- = B1 and Sequence3


E4 = C0 and Sequence3

B- = Sequence4

A - = B0 and Sequence4

E1 = A0 and Sequence4

pneumatic circuit schematic



3. 3 phase electric motor control system


This project demonstrates how to control a three-phase motor using electrical diagrams divided into control and power circuits. It covers multiple motor control methods such as forward/reverse direction, Star-Delta configuration, dual-speed control, and braking systems.

Key Features:

- Separated control and power diagrams
- Forward/reverse direction control
- Star-Delta and dual-speed motor control

Technology: 3-Phase Motor, Contactor, Relay, Timer, Electrical Control Circuit


- clockwise and counter clockwise



Analysis:

- On Control circuit when **Push Button 1 pressed**, it will make **Contactor 1 connect self-holding** and **contactor 2 disconnected**, on the other hand, when **Push Button 2 pressed**, it will make **Contactor 2 connect self-holding** and **contactor 1 disconnected**,
- On **power circuit**, when **Contactor 1 active**, **R** phase connect to **U**; **S** phase connect to **W**; **T** phase connect to **V**; while **X,Y,Z** will connect each other. It will makes motor running clockwise.
- On **power circuit**, when **Contactor 2 active**, **R** phase connect to **V**; **S** phase connect to **W**; **T** phase connect to **U**; while **X,Y,Z** will connect each other. It will makes motor running counter clockwise. The simply we can trade 2 wire to make running motor counter clockwise.



- Star Delta



Analysis:

- On Control circuit when **Push Button Y** pressed to active contactor 1 and 2 its mean on **R** phase connect to **U** and **Z**; **S** phase connect to **V** and **X**; **T** phase connect to **W** and **Y**. this connection makes a **START CIRCUIT**. Start circuit is used to preventing significantly increased current spikes in a short period of time when a 380V motor is switched on.
- Next, when **Push Button Delta** pressed, on the control circuit, it will disconnect contactor 2 and at the same time it will connect contactor 1 and 3. Its mean that **R** phase connect to **U**; **S** phase connect to **V**; **T** phase connect to **W**; while **X,Y,Z** will connect each other.

- 2 Speed / YY






Analysis:

- On Control circuit when **Push Button 1 pressed** to active contactor 1; disconnected contactor 2 and 3. Its mean that **R** phase connect to **U**; **S** phase connect to **V**; **T** phase connect to **W**; while **X,Y,Z** will connect each other. Its same like **delta circuit**
- Next, when **Push Button 2 pressed**, on the control circuit, it will disconnect contactor 1 and at the same time it will connect contactor 2 and 3. Its mean that **R** phase connect to **X**; **S** phase connect to **Y**; **T** phase connect to **Z**; while **U,V,W** will connect each other. This circuit will make speed motor faster than before.

- **Braking**

we can choose one of them to do a braking system






Sequence

- **Contactor 2 and 4 = star circuit**
- **Contactor 2 and 6 = delta circuit**
- **Contactor 8 = braking system**

4. Programmable Logic Control : Plant Temperature – Level - Pressure



This automatic distillation system uses level, temperature, and pressure sensors to simulate essential oil production.


- The **level sensor** controls the pump based on tank water level.
- The **temperature sensor** activates or stops the heater.
- The **pressure sensor** opens or closes a valve to regulate pressure for optimal oil quality.

Key Features:


- Automated distillation process
- Multi-sensor and actuator control
- Real-time pressure and temperature regulation

Technology: PLC, Level Sensor, Temperature Sensor, Pressure Sensor, Valve Actuator

- **Flowchart**



- **Sequence Diagram**



Set Parameter = low level, high level, low temperature, high temperature, low pressure, high pressure

A+ = Pb.sec1

e2 = a1.sec1

A- = Sec2

B+ = a0.sec2

C+ = b1.Sec2


e3 = c1.sec2

B- = Sec3

C- = Sec3


e1 =bo.co.Sec3


- Wiring Diagram – PLC CP1H type CPU XA



- | | | | |
|---|--------------|---|----------------------|
| 1 | PB On | 5 | Pompa |
| 2 | PB Start | 6 | Heater |
| 3 | PB Emergency | 7 | Valve |
| 4 | PB Reset | 8 | Indicator High Level |
| | | 9 | Indicator Low Level |

- HMI Designed





5. Data Communication


This project monitors henhouse conditions via an Android app. The ultrasonic sensor detects feed level — if the distance is too high, the feed is empty, and an LED indicator turns on. The temperature sensor monitors environmental temperature and humidity, triggering an indicator if values are abnormal.

Key Features:

- Android-based remote monitoring
- Automatic feed and temperature detection
- LED visual indicators for abnormal conditions

Technology: Arduino, Ultrasonic Sensor, DHT11, Android App, Wi-Fi Module



Wiring Diagram



Structure Database with Firebase

```
projectkdt2
  --- Keadaan_Lampu: "Sangat_Terang"
  --- Kelembaban: 68
  --- LED1: "1"
  --- LED2: "1"
  --- LED3: "1"
  --- Suhu: 29.1
  --- Ultrasonik: "1207"
  --- Wadah_Pakan: "Kosong"
  --- pijar: "255"
```

Result



6. Data Acquisition : Control and monitor Henhouse : Temprature, Ultrasonic and water level (with Android Application)

Description :


This IoT-based chicken coop management system monitors and controls feeding, drinking, and temperature via Android. It uses three sensors and actuators connected to Firebase for real-time data storage and control.

Key Features:

- IoT-based control and monitoring
- Firebase and Android integration
- Multi-sensor, multi-actuator automation

Technology: ESP32, Ultrasonic Sensor, DHT11, Water Level Sensor, Firebase, Android

Wiring electrical :



Result



CONTROL SCREEN (10:53 AM)

OUTPUT	STATUS
LED	OFF
WATER PUMP	OFF
SERVO	OFF

MONITORING MODE SCREEN (11:20 AM)

- SUHU KANDANG:** 27.6 °C
Status Suhu : Dingin
Kelembaban : 75 %
- STOK PAKAN:** 13 CM
Wadah Makanan : Kosong
- LEVEL AIR MINUM:** 20 ML
Wadah Minuman : Kosong
- Status Aktuator:**
WATER PUMP ON
LAMPU ON
SERVO ON

DATABASE SCREEN (2:01 PM)


Tampilan

Timestamp	Parameter	Value
(2:01:04 pm)	Kelembaban	:10%
	Suhu	:1°C
	Status Suhu	:2
	Keduaan Lampu	:Lampu OFF
	Jarak Pakan	:7cm
	Kondisi Wadah	:8
	Keduaan Servo	:Servo OFF
	Ketinggian Air	:4cm
	Status Air	:5
	Keduaan Pompa	:Water Pump OFF
(2:01:04 pm)	Kelembaban	:10%
	Suhu	:1°C
	Status Suhu	:2
	Keduaan Lampu	:Lampu OFF
	Jarak Pakan	:7cm
	Kondisi Wadah	:8
	Keduaan Servo	:Servo OFF
	Ketinggian Air	:4cm
	Status Air	:5
	Keduaan Pompa	:Water Pump OFF

Youtube simulation : <https://www.youtube.com/watch?v=CUOgQmq9LQ4>

7. Production Planning Control

Product : Teaching Aid Pneumatic




This teaching aid demonstrates **Production Planning and Control (PPC)** using pneumatic and electro-pneumatic components. The system includes 17 parts such as single/double cylinders, 3/2 and 5/2 valves, OR/AND fittings, and one-way flow controls.


Key Features:

- Comprehensive pneumatic setup
- Full PPC process simulation
- Electro-pneumatic integration

Technology: Pneumatics, PLC, Electro-Pneumatic System



Structure of Product




Standard Operational


1. Use Pneumatic Teaching Aid at room temperature
2. Use Pneumatic Teaching Aid at Normal humidity
3. Open the Pneumatic Teaching Aid Suitcase in a horizontal position
4. Connect the air source to the Pneumatic regulator
5. Avoid sources of air with flammable gas content
6. Make sure the air pressure is not more than 4.5 bar
7. Connect the power source to a 24 VDC
8. Pneumatic Teaching Aid is ready to use
9. After using Pneumatic Teaching Aid, inventory components and ensure that no equipment is lost / damaged. The number of components can be checked by looking at the inventory card
10. Close the suitcase slowly and lock it.
11. Store Pneumatic Teaching Aid properly, not stacked, and not stored at the end of the table to prevent the suitcase from falling

Scheduling and Networking

ID	Task Mode	Task Name	Duration	Start	Finish	Predecessors
1		Manually Scheduled	101 days	Mon 04/01/21	Mon 24/05/21	
2		Initiation	12 days	Mon 04/01/21	Tue 19/01/21	
3		Concept Product	4 days	Mon 04/01/21	Thu 07/01/21	
4		Measure competitors	3 days	Fri 08/01/21	Tue 12/01/21	3
5		Develop a unique Product	5 days	Wed 13/01/21	Tue 19/01/21	4
6		General Concept Description	2 days	Wed 20/01/21	Thu 21/01/21	
7		Project Schedule Planning	2 days	Wed 20/01/21	Thu 21/01/21	5
8		Drafting	1 day	Wed 20/01/21	Wed 20/01/21	5
9		General Design Descriptions	9 days	Fri 22/01/21	Wed 03/02/21	
10		Designing mechanical components	4 days	Fri 22/01/21	Wed 27/01/21	7,8
11		Designing Pneumatic components	2 days	Thu 28/01/21	Fri 29/01/21	10
12		Designing Electrical components	1 day	Mon 01/02/21	Mon 01/02/21	11
13		Product design verification	2 days	Tue 02/02/21	Wed 03/02/21	12
14		General Material Component Descriptions	4 days	Thu 04/02/21	Tu 09/02/21	
15		List of components and sorting of materials available	2 days	Thu 04/02/21	Fri 05/02/21	13
16		Price list of survey materials	3 days	Thu 04/02/21	Mon 08/02/21	13
17		Bill of material	1 day	Tue 09/02/21	Tue 09/02/21	15,16
18		Ordering Materials	42 days	Wed 10/02/21	Thu 08/04/21	
19		Verify material list	1 day	Wed 10/02/21	Wed 10/02/21	17
20		Order	40 days	Thu 11/02/21	Wed 07/04/21	19
21		Check the order material	1 day	Thu 08/04/21	Thu 08/04/21	20
22		Preparation	44 days	Wed 10/02/21	Mon 12/04/21	



Page 1



A = Concept Product
B = Measure Competitors
C = Develop Unique Product
D = Project Schedule Planning
E = Drafting

F = Designing mechanical components
G = Designing Pneumatic components
H = Designing Electrical components
I = Product design verification
J = List of components and sorting of materials available

K = Price list of survey materials
L = Bill of material
M = Verify material list
N = Create Manual Book
O = Check the order material

P = Project Plan
Q = Prepare the requirement
R = Request Power
S = Create Manual Book
T = Prepare OF / Work Plan Met
U = Preparing Materials

V = Mechanical Part processing
W = Material planning
X = Prepare OF / Work Plan Met
Y = Preparing Tools and tool components
Z = Project OF / Work Plan Electric

A1 = Color and brand check
A2 = High Pressure Test
A3 = Create Manual Book
A4 = Mechanical parts inspection
A5 = Setting
A6 = Hinges and Casting

A7 = Color and brand check
A8 = Shipping (Domestic)
A9 = SAT Date Acceptance Test
A10 = SAT Date Acceptance Requirements
A11 = Issue a final payment request
A12 = Evaluation Meeting

Man Power

No	Design	Object	Activity	Time	Labor Rates	NoP	Amount	Information
1	Design	Initiation	Concept Product	2 days	Rp3.713.696	1	Rp3.713.696	Project Manager;Finance & Business Management
2			Measure Competitors	2 days	Rp3.448.432	1	Rp3.448.432	Secretary production
3			Develop a unique Product	1 day	Rp5.950.860	1	Rp5.950.860	Project Manager;Sales Marketing 1
4		General Concept Description	Project Schedule Planning	2 days	Rp3.183.168	1	Rp3.183.168	Finance & Business Management;Project Manager
5			Drafting	1 day	Rp2.917.904	1	Rp2.917.904	Finance & Business Management;Project Manager
6			Designing mechanical components	4 days	Rp4.314.176	1	Rp4.314.176	Designer Engineer;Drafter
7			Designing Pneumatic components	2 days	Rp3.755.008	1	Rp3.755.008	Designer Engineer;Drafter
8			Designing Electrical components	1 day	Rp3.475.424	1	Rp3.475.424	Designer Engineer;Drafter
9		General Material Component Descriptions	Product design verification	2 days	Rp3.211.296	1	Rp3.211.296	Project Manager
10			List of components and sorting of materials available	2 days	Rp743.744	1	Rp743.744	General Service;IT Staff 1
11			Price list of survey materials	3 days	Rp3.744.520	1	Rp3.744.520	Consultant Material
12			Bill of material	1 day	Rp2.958.296	1	Rp2.958.296	Consultant Material;Secretary production
13	Ordering Materials	Verify material list	1 day	Rp2.943.688	1	Rp2.943.688	Project Manager	
14			Order	40 days	Rp0	1	Rp0	
15		Check the order material	1 day	Rp3.168.440	1	Rp3.168.440	Consultant Material	

Bill Of Material

BILL OF MATERIAL PNEUMATIC TEACHING AID								
Item No	Description	Detail	Unit	Qty	Unit Price	Total Price	Supplier	Image
1	Seven ACP PVDF Glossy	1). This is 600 * 450 mm 2). Thick 4 mm 3). Weight: 8.1Kg/m.	pcs	1	Rp	475.000,00	Rp	475.000 PT Impact Pratama.
2	Black ABS Aluminum Tool Case	1). Design: Tool-MS1701 2). Size: 460*310*150mm 3). Material: ABS 4). Locks, handle with shoulder strap.	pcs	1	Rp	330.000,00	Rp	330.000,00 MSAC CO., LTD
3	SMC Standard Air Cylinder CHB20-75Z Double Acting	1). Stroke (mm) 75 2). Cushion Rubber cushion Pipe 3), Port Diameter 2 x R1/8	pcs	2	Rp	649.000,00	Rp	1.298.000 SMC Corporation.
4	Rectangular Multi-connector KDM10P-04	1). Type: Connecting Plug Tube 2). Tubing Outside Diameter: 4mm 3). No Of Tube: 10	pcs	1	Rp	770.000,00	Rp	770.000,00 SMC Corporation.
5	3/2 VM1000-4N-01 Roller Level	1). Conformity Tube Outside Diameter (mm) 4 2). Number of Ports 3 Port 3). Operating Pressure Range (Mpa) 0 to 0.6 4). Actuator Type Roller Lever	set	6	Rp	464.000,00	Rp	2.784.000,00 SMC Corporation.
6	OR Fitting VR12 Series	1). Logic Function OR 2). Connection Type: Tube 3). Tube Connections: 4mm	pcs	5	Rp	370.000,00	Rp	1.850.000,00 SMC Corporation.
7	AND Fitting VR12 Series	1). Logic Function AND 2). Connection Type: Tube 3). Tube Connections: 4mm	pcs	5	Rp	370.000,00	Rp	1.850.000,00 SMC Corporation.

8. Distributed Control System (DCS) Integration

Description

This project monitors a testing station using **Wonderware Intouch** as the HMI, with **Omron** and **Siemens PLCs** acting as control stations. Data communication is managed via **KepServerEX6**.

Key Features:

- Multi-PLC integration
- Wonderware Intouch HMI
- Real-time industrial data communication

Technology: Wonderware Intouch, Omron PLC, Siemens PLC, KepServerEX6

Communication Wiring


Connect PLC and PC with Switch HUB




Network ID

IP PLC OMRON : 192.168.10.16


IP PLC Siemens : 192.168.10.6



Design KepServerEX6 and Wonderware Intouch



Result



9. SCADA and DCS Study Casus

- Description


This SCADA/DCS project allows remote monitoring and control of multiple production plants using **Wonderware Intouch**. Data is logged to **SQL Server** and **Excel**, enabling centralized supervision and production analysis.

Key Features:



- Multi-plant remote monitoring
- Automated data acquisition and logging
- SQL Server and Excel integration


Technology: Wonderware Intouch, SCADA/DCS, SQL Server, Data Logging

- Design



- Wiring






Output




Indicator






Pneumatic

Design HMI



Result





10. Internship Project : Control and Monitor Air Conditioner Server room Polman Bandung

Description :


This system controls three air conditioners in the **Polman Bandung** server room, alternating every two days. Temperature data is stored in **MySQL** and **Antares**, with automatic notifications sent to operators when temperatures exceed thresholds.

Key Features:


- Automatic rotation of three AC units
- Cloud-based temperature logging
- Ultrasonic motion detection for lighting control

Technology: ESP32, Ultrasonic Sensor, MySQL, Antares IoT, Cloud Notification

Design system



Wiring



Bill of Material

Page 1


Implementation



Notification to Operator Telegram



Monitoring in operator PC



11. Internship Project : Control Ventilator Indonesia

Description :


This ventilator system was designed for COVID-19 patients, featuring **Volume Control** and **Pressure Control** modes. It uses pressure, oxygen, and flow sensors to calculate control parameters for the servo motor. Equipped with HMI alarms and integrated with **Node-RED** for remote monitoring.

Key Features:

- Dual control modes (Volume/Pressure)
- HMI with visual and audible alarms
- Node-RED-based monitoring

Technology: ESP32, Pressure Sensor, Flow Sensor, Node-RED, HMI

Design



Interface HMI

Control Mode:		Mandatory Volume Control																					
<p>Choose Use Option</p> <p>MANDATORY VOLUME CONTROL</p> <p>MANDATORY PRESSURE CONTROL</p> <p>ASSISTED VOLUME CONTROL</p> <p>ASSISTED PRESSURE CONTROL</p> <p>CALIBRATION PAGE APPLY</p> <p>Alarm</p> <table border="1"> <tr> <td>HIGH PRESS</td> <td>LOW PRESS</td> <td>RESET</td> </tr> <tr> <td>FIGHTING</td> <td>EMERGENCY</td> <td></td> </tr> <tr> <td>SPURIOUS</td> <td>OVER VOL</td> <td>MUTE</td> </tr> <tr> <td>LOW PEEP</td> <td>LOW/HIGH O₂</td> <td></td> </tr> </table>				HIGH PRESS	LOW PRESS	RESET	FIGHTING	EMERGENCY		SPURIOUS	OVER VOL	MUTE	LOW PEEP	LOW/HIGH O ₂									
HIGH PRESS	LOW PRESS	RESET																					
FIGHTING	EMERGENCY																						
SPURIOUS	OVER VOL	MUTE																					
LOW PEEP	LOW/HIGH O ₂																						
<p>Setting</p> <p>I:E (ratio) v 1:2 ^</p> <p>RR (bpm) v 30 ^</p> <p>FiO₂ (%) v 10 ^</p> <p>PEEP (cmH₂O) v 3 ^</p> <p>VTi (mL) v 300 ^</p> <p>BACK NEXT</p>		<p>Alarm</p> <table border="1"> <tr> <td>HIGH PRESS</td> <td>LOW PRESS</td> <td>RESET</td> </tr> <tr> <td>FIGHTING</td> <td>EMERGENCY</td> <td></td> </tr> <tr> <td>SPURIOUS</td> <td>OVER VOL</td> <td>MUTE</td> </tr> <tr> <td>LOW PEEP</td> <td>LOW/HIGH O₂</td> <td></td> </tr> </table>		HIGH PRESS	LOW PRESS	RESET	FIGHTING	EMERGENCY		SPURIOUS	OVER VOL	MUTE	LOW PEEP	LOW/HIGH O ₂									
HIGH PRESS	LOW PRESS	RESET																					
FIGHTING	EMERGENCY																						
SPURIOUS	OVER VOL	MUTE																					
LOW PEEP	LOW/HIGH O ₂																						
<p>Control Mode: Mandatory Volume Control</p> <p>Setting</p> <p>High Press Limit (cmH₂O) v 70 ^</p> <p>Low Press Limit (cmH₂O) v 0 ^</p> <p>O₂ Tolerance (%) v 5 ^</p> <p>BACK NEXT</p>		<p>Control Mode: Mandatory Volume Control</p> <table border="1"> <tr> <td>RR bpm</td> <td>PIP cmH₂O</td> <td>FiO₂ %</td> <td>PIF LPM</td> </tr> <tr> <td>I:E 1:</td> <td>IPP cmH₂O</td> <td>PEEP cmH₂O</td> <td>VTi_a mL</td> </tr> </table> <p>USE MENU START</p> <p>Set Value: 1:2 RR 30 bpm VTi 300 mL PEEP 3 cmH₂O</p> <p>Alarm</p> <table border="1"> <tr> <td>HIGH PRESS</td> <td>LOW PRESS</td> <td>RESET</td> </tr> <tr> <td>FIGHTING</td> <td>EMERGENCY</td> <td></td> </tr> <tr> <td>SPURIOUS</td> <td>OVER VOL</td> <td>MUTE</td> </tr> <tr> <td>LOW PEEP</td> <td>LOW/HIGH O₂</td> <td></td> </tr> </table>		RR bpm	PIP cmH ₂ O	FiO ₂ %	PIF LPM	I:E 1:	IPP cmH ₂ O	PEEP cmH ₂ O	VTi _a mL	HIGH PRESS	LOW PRESS	RESET	FIGHTING	EMERGENCY		SPURIOUS	OVER VOL	MUTE	LOW PEEP	LOW/HIGH O ₂	
RR bpm	PIP cmH ₂ O	FiO ₂ %	PIF LPM																				
I:E 1:	IPP cmH ₂ O	PEEP cmH ₂ O	VTi _a mL																				
HIGH PRESS	LOW PRESS	RESET																					
FIGHTING	EMERGENCY																						
SPURIOUS	OVER VOL	MUTE																					
LOW PEEP	LOW/HIGH O ₂																						

Implementation



12. Final Project : Design and Build Multi Device Infusion Control and Monitoring System Based on the Internet of Things



This IoT-based research project develops three infusion devices capable of flowrate control and hazard monitoring, including air bubble detection, blockage, and empty infusion. Data is transmitted via **MQTT** to a **Node-RED Server**, visualized on **Nextion HMI** and nurse monitoring screens. Each device includes a mini UPS for power backup. There is motor servo can control how much the pressing to pipe infusion using PID base on flowrate that set by the operator.

Key Features:

- Multi-device infusion control and monitoring
- Cloud communication using MQTT protocol
- Real-time hazard detection and power backup
- PID flowarate with servo motor and infrared sensor calculation

Technology: ESP32, IR & Bubble Sensors, Servo Motor, Node-RED, MQTT, MySQL, UPS

Flowrate PID Control



HMI Nextion



Dashboard in Server Room

MONITORING INFUS

LOGIN REGISTER

0:15 / 0:21

MIFUS 1

BACK

Flowrate

Flowrate1

200.00

Flowrate

14.21.23 14.21.53 14.22.23 14.22.53 14.23.23 14.23.53 14.24.23 14.24.53 14.25.26

Volume

Volume1

100.00

Volume

14.21.23 14.21.53 14.22.23 14.22.53 14.23.23 14.23.53 14.24.23 14.24.53 14.25.26

Volume

Volume1

100.00

Volume

14.22.23 14.22.53 14.23.23 14.23.53 14.24.23 14.24.53 14.25.23 14.25.53 14.26.27

TERDAPAT SLEMBUNG

VOLUME HABIS

CIRIAN TERSUMBAT

VOLUME BERLEBIH

FLOWRATE SALAH

UPDATE TABLE

Tanggal	Jam	Jenis Alarm
2022-06-15	17:43:38	Flowrate Salah
2022-06-15	17:43:43	Flowrate Salah
2022-06-15	17:44:23	Flowrate Salah
2022-06-15	17:44:26	Flowrate Salah
2022-06-15	17:44:27	Flowrate Salah
2022-06-15	17:44:29	Flowrate Salah
2022-06-15	17:44:33	Flowrate Salah
2022-06-15	17:44:36	Flowrate Salah